


Wireless Voyager Default Layout







S — A regular key


Left Alt — A modifier key (Shift, for example)


A key with more than one function

LED Control

Prev Tab — A key with a user-defined label

Wireless Voyager Default Layout





S — A regular key

Left Alt — A modifier key (Shift, for example)

A key with more than one function

LED Control

Prev Tab — A key with a user-defined label